

SC-200 Screen-Crawler®

De Screen-Crawler is geschikt voor een maximale belasting van 200 Kg aan de haak. Het product is alleen geschikt voor het heffen van lasten, voorzien van een degelijke montage, gebruikmakend van degelijke hijsmiddelen.

Gebruiksaanwijzing:

- Plaats de Screen-Crawler® te allen tijde op een vlakke, stevige ondergrond.
- Plaats de Screen-Crawler® onder een hoek van 70-75 graden ten opzichte van de stevige muur.
- Trek aan de band om de Screen-Crawler® uit te trekken tot de gewenste gebruikshoogte.
- Borg de telescopische functie van de mast.
- De last moet altijd symmetrisch onder de haak hangen, altijd waterpas.
- Zorg dat de kabel altijd netjes oprolt op de katrol; zorg dat er geen knikken komen in de kabel. De kabel mag niet kruisen op de katrol
- Laat altijd minimaal 3 windingen over op de katrol.
- Gebruik het verlengstuk om grotere afstanden te kunnen overbruggen naar de wand / muur.



Veiligheidsregels:

- De gebruiker dient op de hoogte te zijn van de ARBO-wet, waarbij het dragen van persoonlijke beschermingsmiddelen zoals kleding en schoenen en "niet onder de mast lopen" extra aandacht krijgt.
- Zet geen ladder of gelijkend tegen de Screen-Crawler®.
- Laat de last nooit zwenken of horizontaal bewegen. Bij een scheve uitlijning t.o.v. de muurbeugel de set opnieuw opzetten.
- Controleer elke keer voor gebruik de Screen-Crawler® op schade, gebreken en volledige werking. Controleer staalkabel, optrekinrichting, anti-slip voeten etc.
- Bij gebreken of twijfel het product niet gebruiken, neem contact op met Audipack
- De Screen-Crawler® dient elk jaar te worden gecontroleerd of onderhouden worden door een deskundige; dit voor het behoudt van het product en de veiligheid van de omstanders.

SC-200 Screen-Crawler®

**The Screen-Crawler® is suitable for a max. load of 200 Kg on the hook.
The product is only suitable for lifting loads, connected / installed with proper certified hoist gear.**

User manual:

- Place the Screen-Crawler® only on flat surfaces, with sufficient grip. The surface must be level.
- Place the Screen-Crawler® at an angle of 70-75 degrees in comparison to the rigid wall.
- Pull the strap to telescopic extend the Screen-Crawler® to the desired height.
- Secure the telescopic function of the product.
- The load must be suspended level and equal to the Screen-Crawler, always level!
- Make sure the hoist cable is organized neatly on the cable drum, do not bend the cable, organize next to each other. Do not cross the cable on the drum.
- Always leave 3 complete windings left on the drum.
- Use the extension part instead of the wheels to generate more space between the hook and wall.



Safety rules:

- The user must be trained and informed about the legal working conditions act, wearing personal safety clothes, shoes etc. Extra attention not to walk below the Screen-Crawler.
- Do not install a ladder / scaffolding against the Screen-Crawler®.
- A load may never swing or be out of balance. At an offset position of the load re-install the Screen-Crawler.
- Check before every use the Screen-Crawler® on damage, function, wear and tear or missing parts, check the cable, telescopic lift function + safety and anti-slip feet.
- When fault are detected do not use the product and contact Audipack
- The Screen-Crawler® must be checked every year by an expert on lifting devices; this for the safety of the user and surrounding persons.