







(4X)   
 (4X) 




392167




392367




392667




392666




392366




392161




392361




392661



392165



392365



392665

NOTE: All dimensions are ±..., in mm and subject to change

© COPYRIGHT AUDIPACK  
 This print and the information shown  
 thereon, is the property of  
 AUDIPACK.  
 It may not be delivered to others nor  
 reproduced for general circulation  
 without the written consent of the  
 AUDIPACK engineering department.




**AUDIPACK**  
 Industriestraat 2-4  
 2751 GT Moerkapelle  
 the Netherlands  
 Tel: +31(0)795931671  
 Fax: +31(0)795933115  
 www.audipack.com


MANUAL  
 392176

BEUGEL


Dimensions are indications, not to be used for any preparations. No rights can be derived from the above dimensions.




UTC-0300




UTS-0500




UTS-0700T




UTC-1000T



UTS-1000T



PWM-0450



NOTE: All dimensions are ±..., in mm and subject to change

© COPYRIGHT AUDIPACK  
 This print and the information shown  
 thereon, is the property of  
 AUDIPACK.  
 It may not be delivered to others nor  
 reproduced for general circulation  
 without the written consent of the  
 AUDIPACK engineering department.



**AUDIPACK**  
 Industriestraat 2-4  
 2751 GT Moerkapelle  
 the Netherlands  
 Tel: +31(0)795931671  
 Fax: +31(0)795933115  
 www.audipack.com

MANUAL  
 392176

BEUGEL

Dimensions are indications, not to be used for any preparations. No rights can be derived from the above dimensions.